







M973 幽灵门安装说明书


M973 Invisible Door Installation Manual

主支架 Upper runner		1	侧边轮 Side runner		2	轨道 Rail		1
下定位轮 Down guide roller		1	地轮 Down runner		2	缓冲器 Soft close device		2



* 安装尺寸仅供参考，以实际安装为准 Date for reference only, install based on your project



Distance 80mm



When installing the lower
wheel, tighten the screws
first, then clip the brush on






木门模式一（门洞全开） Front view method 1 (Door fully open)

门宽度尺寸:

$$W = X + 220$$

Door width: $W = X + 220$




木门模式二（门洞未全开） Front view method 2 (Door not fully open)

门宽度尺寸 $W = X + T$

$T \geq 110$ mm

(T必须 ≥ 110 mm)


Door width: $W = X + T$



主支架中心
对齐门洞边


注意:当 $T \geq 110$ mm 时,
主支架位置“ ”
顺箭头方向相应移动
“T-110”

Align the center upper
runner with the edge
of doorway opening,
if $T \geq 110$ mm, move
upper runner to
“T-110mm” accordingly




安装上轮支架

Fasten the upper runner




安装下定位轮

Screw the down guide roller




拧紧安全扣的螺丝

Tight up the screw of safty lock clip




装门

Hang up the door



调节上下 Adjust the height



拧紧安全扣的螺丝

Tight up the screw of safty lock clip

